

INSTALLATION INSTRUCTIONS:

1. Position hooks at desired location
2. Mark hook locations
3. Drill 3/32" pilot holes on marked hook locations
4. Install hooks
5. Attach spring to hooks and crimp hooks closed
6. Adjust tension as necessary

TOOLS REQUIRED:

Pencil, drill, 3/32" drill bit, pliers

INSTRUCTIONS POUR L'INSTALLATION

1. Placer les crochets aux emplacements souhaités
2. Marquer l'emplacement des crochets
3. Percer des trous pilotes de 2,38 mm aux emplacements marqués pour les crochets
4. Installer les crochets
5. Attacher le ressort-tendeur aux crochets et fermer ceux-ci avec la pince
6. Régler la tension du ressort selon les besoins

OUTILS REQUIS : Crayon, perceuse, mèche de 2,38 mm, pinces

INSTRUCCIONES DE INSTALACIÓN:

1. Coloque los ganchos en los sitios deseados.
2. Marque los sitios de los ganchos.
3. Perfore agujeros piloto de 2.4 mm (3/32") en los sitios marcados para los ganchos.
4. Instale los ganchos.
5. Conecte el resorte tensor a los ganchos y apriete los ganchos para cerrarlos.
6. Ajuste la tensión según se requiera.

HERRAMIENTAS REQUERIDAS: Lápiz, taladro, broca de 2.4 mm (3/32"), pinzas/alicates

