

FEATURES: • Full 1-3/4" length • For holding window and door panels in place

INSTALLATION INSTRUCTIONS:

STEP 1. Position turnbutton in desired location

STEP 2. Mark screw location

STEP 3. Drill 7/64" pilot hole on marked screw location

STEP 4. Fasten turnbutton with screws provided - **NOTE:** Do not over tighten.

TOOLS REQUIRED: Pencil, #2 Phillips screwdriver, drill, 7/64" drill bit

CARACTÉRISTIQUES : • Longueur totale de 4,45 cm (1-3/4 po)

• Pour maintenir les panneaux de fenêtre et de porte en place

INSTRUCTIONS POUR L'INSTALLATION :

ÉTAPE 1. Placer le bouton tournant à l'emplacement souhaité

ÉTAPE 2. Marquer l'emplacement de la vis

ÉTAPE 3. Percer un trou pilote de 2,78 mm (7/64 po) à l'emplacement marqué de la vis

ÉTAPE 4. Fixer le bouton tournant avec les vis fournies - **REMARQUE :** Ne pas trop serrer.

OUTILS REQUIS : Crayon, tournevis cruciforme n° 2, perceuse, mèche de 2,78 mm (7/64 po)

CARACTERÍSTICAS: • Longitud total de 44.45 mm • Para mantener a los paneles de ventanas y puertas en su lugar

INSTRUCCIONES DE INSTALACIÓN:

PASO 1. Coloque la mariposa en el sitio deseado.

PASO 2. Marque el sitio del tornillo.

PASO 3. Perfore un agujero piloto de 2.8 mm (7/64") en el sitio marcado para el tornillo.

PASO 4. Fije la mariposa con un tornillos provisto. - **NOTA:** No lo apriete demasiado.

HERRAMIENTAS NECESARIAS: Lápiz, desarmador de cruz Phillips #2, taladro, broca de taladro de 2.78 mm (7/64").

